
Subject: Re: TPC dE/dx

Posted by [Felix Boehmer](#) on Tue, 08 Mar 2011 16:03:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Stefano,

very cool that you look into this!

Just some comments:

The cluster amplitude is defined after the FrontEnd and given in ADC channels! It is calculated from the analogue signal amplitude (on the pad) using some parameters: $ADC_amp = Sig_amp / (adcmax/adcmaxcount)$ (See PndTpcFrontend).

You have to be very careful when defining the dx - a lot of effects are at work here (clustering!). The best approach is to use the actual track fit, as it is done in the task that I sent you a while ago

Cheers

Felix