
Subject: Regarding digitization of start detector of diamond
Posted by [Shyam Kumar](#) on Tue, 25 Mar 2014 15:16:29 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi,

I am setting the parameter for diamond sensors in macro/params/all.par file similar as "Digitization parameters for TRAPEZOID Mvd strip sensors" but I did not understand the last term "cluster_corrchargecut:Double_t 12000." exactly and also there is a question we have two types of trapezoid sensors (small and large) should I use different parameters(as top anchor and skew and orient etc.) for both or same for both.

Thank you
