

---

Subject: Re: Question about pipe simulation

Posted by [Stefano Spataro](#) on Wed, 29 Jul 2009 09:49:28 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Before there were two pipe geometry: one with only the beam pipe (pipe.geo), the other even with the target pipe.

Now those files are not used anymore. As ralf was writing, the pipe geometry is created inside the PndPipe class.

---