
Subject: Re: FRS - TPC Calibrations

Posted by [mlcortes](#) on Wed, 03 Jun 2015 12:31:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Tayfun,

In general, each TPC has 4 y outputs and 2 x outputs. You can check it more in detail in the TPC manual. So, with some hope you can still use at least one for each direction. The x and y outputs are the average of those values.

I just now noticed that we may be using different processors, so here I copy my config file:

```
processor Frs/TpcS41 FRS.TPC
times[0:7]      <- FrsTpcCrate.tdc1[0:7]
amplitudes[0:7] <- FrsTpcCrate.adc1[0:7]
fiber          <- FrsTpcCrate.tdc1[23]
display  x:y    500,-50,50:500,-50,50 in TPCs/TpcS41
display  y      500,-50,50           in TPCs/TpcS41
display  x      500,-50,50           in TPCs/TpcS41
display  xs     500,-50,50           in TPCs/TpcS41
display  ys     500,-50,50           in TPCs/TpcS41
# display  x_fiber:y_fiber           in TPCs/TpcS41
display  checksums | gate_checksums 5000,-2000,3000 in TPCs/TpcS41/checksums
end
```

Here this different outputs are called xs and ys. I think for the processor called StandardTpc (and not TPC), the different xs and ys are called xc and yc.

Taking care about using the correct inputs, can you please try to run this and get the xs and ys? (And also the x vs y for the mask runs)

Liliana
