
Subject: Re: Particle reached max step number
Posted by [Dmytro Kresan](#) on Thu, 18 Aug 2016 08:53:10 GMT
[View Forum Message](#) <> [Reply to Message](#)

In your case with actar simulations, you need to adjust two files in gconfig directory:
g4GarfieldConfig.C and g4garfieldconfig.in

In first you can set maximum number of steps.
You can set only maximum step length. The minimum step size is controlled by energy cut for
a specific particle / process, larger cut --> larger step size. Refer to Geant4 manual.

I saw also that you need to change garfield region in g4garfieldconfig.in to helium.

Best regards,
Dima
