

---

Subject: step length for VMC

Posted by [Artem Basalaev](#) on Fri, 18 May 2012 08:53:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello!

Please tell me how can I set maximum step length for particles (geantino) transport through geometry. I use standard macro runMC.C and Geant3 as VMC.

---

---

Subject: Re: step length for VMC

Posted by [Mohammad Al-Turany](#) on Mon, 09 Jul 2012 14:04:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hallo Artem,

In Geant3 this can be done via media and not particles, see:

<http://fairroot.gsi.de/?q=node/34>

you can set the maxstep size for a certain material and then it is valid for all particles passing this media, you should be carfull when using this because fit could produce non-physical results (energy loss calculation is effected!)

regards,

Mohammad

---