

---

Subject: Re: New Solenoid and MVD

Posted by [Stefano Spataro](#) on Thu, 03 Apr 2008 16:42:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Tobias,

I have tried to use your Solenoid.root file as input for the magnet geometry, and I get the following error:

Processing run\_sim.C...

```
- RTDB container factory PndSttContFact
- RTDB container factory PndMuoContFact
- RTDB container factory PndDrcContFact
- RTDB container factory PndTofContFact
-I- CbmRun::SetMaterials() Media file used:
/home/spataro/dev/pandaroot/geometry/media_pnd.geo
```

```
===== CbmRunSim: Initialising simulation run =====
Info in <TGeoManager::TGeoManager>: Geometry CBMGeom, CBM geometry created
-I- CbmGeoMedia Read media
CbmRunSim::Init() create visualisation manager
-I- PndFieldMap: Reading field map from ROOT file
/home/spataro/dev/pandaroot/input/TransMap.root
-I- PndFieldMap: Reading field map from ROOT file
/home/spataro/dev/pandaroot/input/DipoleMap.root
-I- PndFieldMap: Reading field map from ROOT file
/home/spataro/dev/pandaroot/input/SolenoidMap.root
Loading Geant3 libraries ...
Loading Geant3 libraries ... finished
```

```
MZSTOR. ZEBRA table base TAB(0) in /MZCC/ at adr 747956495 2C94E90F HEX
```

```
MZSTOR. Initialize Store 0 in /GCBANK/
with Store/Table at absolute adrs 748065341 747956495
      HEX 2C96923D 2C94E90F
      HEX 1A77A 0
      relative adrs 108410 0
with 1 Str. in 2 Links in 5300 Low words in 4999970 words.
This store has a fence of 16 words.
```

```
MZLOGL. Set Log Level 0 for store 0
1***** GEANT Version 3.21/11 Released on 100298
0***** Correction Cradle Version 0.1100
```

```
MZDIV. Initialize Division Constant in Store 0
NW/NWMAX= 20004000000, MODE/KIND= 1 2
Division 20 initialized.
```

```
MZLINK. Initialize Link Area /GCLINK/ for Store 0 NL/NS= 20 20
```

```
MZLINK. Initialize Link Area /GCSLNK/ for Store 0 NL/NS= 100 100
-I- G3Config: Geant3 with TGeo has been created.
Physics cuts with script
```

/home/spataro/dev/pandaroot/gconfig/SetCuts.C

SetCuts Macro: Setting Processes..

SetCuts Macro: Setting cuts..

Info in <TGeoManager::SetTopVolume>: Top volume is cave. Master volume is cave

Info in <TGeoManager::CloseGeometry>: Geometry loaded from file...

Info in <TGeoManager::SetTopVolume>: Top volume is TOP. Master volume is TOP

Info in <TGeoManager::CloseGeometry>: Voxelization retrieved from file

Info in <TGeoNavigator::BuildCache>: --- Maximum geometry depth set to 100

Info in <TGeoManager::CloseGeometry>: 85 nodes/ 59 volume UID's in CAD to Root

Info in <TGeoManager::CloseGeometry>: -----modeler ready-----

-W- WARNING in CbmModule::ExpandNode()!      The volume Coilo1 Has no medium information.

Or better, it is a warning but after the program exits.

Maybe there are some problems with the media?